



Analog Devices Warpstor appliance evaluation.

Warpstor appliance installation notes

eth1 LAN port should be used for the management network. It is configured for static IP address.

eth0 LAN port is configured for DHCP address assignment. It can be configured for an extra 1Gb Ethernet LAN port if one is needed, otherwise it should not be used.

eth2 and eth3 are the twinax 10GbE ports, and are located on the expansion card. They are also statically configured.

eth4 and eth5 are 10Kbase-T 10GbE ports and are not configured for use in this evaluation.

Box contents

1. Warpstor appliance
2. Warpstor appliance power cord
3. Rack mounting hardware
4. Installation guide and notes.